




# SPARE PARTS LIST

BLOWERS

356 BT




## HANDLE &amp; CONTROLS

356 BT

Part No	Description	Remark	QTY KIT
502 20 40-01	KNOB		1
503 20 07-35	SCREW IHSCFM		1
503 21 29-06	SCREW CCRPANT		1
503 21 66-18	SCREW IHSCT		2
503 22 10-13	HEXAGON NUT		1
503 22 65-04	SQUARE NUT		1
537 00 68-01	HANDLE ASSY	Up to 081370240	1
537 14 10-01	LEVER		1
537 14 12-01	SHAFT		1
537 14 20-01	HANDLE HALF		1
537 14 25-01	CASE		1
537 16 08-01	THROTTLE TRIGGER		1
537 17 42-01	SPRING THROTTLE TRIG		1
537 21 64-01	STOPPER		1
537 22 62-01	CONNECTOR		1
537 22 63-01	CONNECTOR		1
537 25 38-01	WIRING ASSY		1
537 26 02-01	STAY		1
537 26 03-01	BRACKET		1
537 27 77-01	PLATE		1
537 37 39-01	SPRING		1
720 12 36-20	PARALLEL PIN		1
725 23 44-51	SCREW EHHM		1
734 11 47-41	WASHER		1
735 58 35-01	WASHER		1


SN 081370241 -



## HANDLE &amp; CONTROLS

356 BT


Ref	Part No	Description	Remark	QTY	KIT
1	522 83 21-01	HANDLE		1	
2	505 19 86-01	WIRING ASSY	From 081370241 BT only	1	1
3	537 22 63-01	CONNECTOR		1	2
4	537 22 62-01	CONNECTOR		1	2
5	505 29 12-01	SCREW		2	1
6	502 24 49-01	HANDLE HALF		1	1
7	505 29 08-01	SCREW		1	1
8	735 58 35-01	WASHER		1	1
9	505 18 15-01	WASHER		1	1
10	537 37 39-01	SPRING		1	1
11	502 24 55-01	CONTROL		1	1
12	505 29 10-01	SCREW		1	1
13	502 24 60-01	RETAINER		1	1
14	537 17 42-01	SPRING THROTTLE TRIG		1	1
15	502 24 54-01	TRIGGER		1	1
16	505 56 79-01	SPRING		1	1
17	502 24 48-01	HANDLE HALF		1	1
18	502 64 17-01	PLATE		1	1
19	537 14 12-03	SHAFT PIVOT		1	1
20	503 22 10-13	HEXAGON NUT		1	1
21	502 24 53-01	HOLDER		1	1
22	503 22 65-04	SQUARE NUT		1	1
23	537 26 03-01	BRACKET		1	1
24	502 20 40-01	KNOB		1	1
25	725 23 44-51	SCREW EHHM		1	1



TUBE

356 BT

Ref	Part No	Description	Remark	QTY KIT
1	537 03 90-01	PIPE		1
2	537 03 89-01	PIPE		1
3	537 41 59-01	COVER		1
4	537 42 27-01	PIPE		1
5	537 40 53-02	BELLOWS		1
6	537 41 58-01	HOSE CLAMP		2
7	537 41 56-01	PIPE BEND		1






## IGNITION SYSTEM

356 BT


Ref	Part No	Description	Remark	QTY	KIT
1	503 20 02-35	SCREW IHSCFM		4	
2	503 20 25-50	SCREW IHSCM		2	
3	505 13 16-01	FLAT PIN	SN 081370241 -	1	
4	544 01 98-03	IGNITION SYSTEM		1	
5	501 48 54-02	SPARK PLUG CAP		1	4
6	503 22 01-02	NUT FLANGE		2	4
7	537 29 37-01	RETAINER		1	4
8	537 41 47-02	CRANKCASE ASSY		1	
9	537 29 66-01	GASKET		1	8, 17
10	544 06 86-01	BALL BEARING		1	8, 17, 18
11	505 27 57-19	SEALING RING		1	8, 18
12	537 06 11-01	GASKET		1	8, 17
13	501 27 08-01	GUIDE BUSHING		4	8
16	537 05 73-01	GUIDE PLATE		1	8
17	537 41 49-01	HUB CAP		1	
18	537 41 46-01	CRANKSHAFT ASSY		1	
19	577 57 24-01	NEEDLE BEARING		1	18
20	503 23 00-01	WASHER		1	




## CYLINDER, PISTON &amp; MUFFLER

356 BT


Ref	Part No	Description	Remark	QTY	KIT
1	537 42 26-01	MUFFLER		1	
2	590 83 89-01	HOSE CLAMP		2	1, 34
3	725 53 83-56	SCREW IHSCM		2	1
4	503 23 04-04	WASHER		2	1
5	537 40 19-01	SPARK ARRESTER SCREEN	US only	1	1
6	544 31 70-02	HOSE CLAMP		1	1
7	537 25 03-01	OUTLET PIPE		1	
8	503 21 75-16	SCREW IHSCFT		1	
9	537 21 76-01	HOSE	- SN 20131170019	1	
9	578 00 82-01	HOSE	SN 20131170020 -	1	34
10	537 22 57-02	PIPE	SN 20131170020 -	1	34
10	579 16 85-01	PIPE	- SN 20131170019	1	
11	537 25 92-01	BRACKET		1	34
12	501 81 99-01	SCREW		1	34
13	544 07 94-01	GASKET		1	
14	537 06 15-01	HEAT DEFLECTOR		1	
15	503 23 51-08	SPARK PLUG	alt. 503 23 51-11	1	
16	725 53 33-55	SCREW IHSCM		4	
17	503 23 04-02	WASHER		1	
18	503 20 02-60	SCREW		1	
19	537 41 50-01	PISTON		1	
20	537 26 18-02	PISTON		1	19
21	503 28 90-10	PISTON RING		2	20
22	737 43 12-00	SNAP RING		2	20
23	503 73 39-01	BEARING		1	20
24	503 28 91-09	PISTON PIN		1	20
25	581 75 61-34	FUEL HOSE		1	
26	544 31 70-03	HOSE CLAMP		1	
27	537 06 17-01	INLET PIPE		1	
28	522 79 63-01	HOSE CLAMP		1	
29	537 17 52-01	BRACKET		1	
30	537 25 49-01	GASKET		1	
31	503 28 31-19	CARBURETTOR		1	
32	503 21 75-50	SCREW IHSCFT		1	
33	537 06 18-02	INLET BEND	SN 081370241 -	1	
34	579 16 85-01	PIPE		1	
35	576 34 58-01	NIPPLE		1	34
36	537 09 86-07	HOSE		1	34
37	581 28 54-01	CLAMP		1	34



Ref	Part No	Description	Remark	QTY KIT	
1	537 05 77-01	HUB CAP		1	
2	537 11 72-01	HUB CAP		1	1
3	537 22 20-01	EXHAUST COVER		1	1
4	735 58 41-00	WASHER		3	1
5	537 11 59-01	HUB CAP		1	1
6	735 58 41-00	WASHER		6	1
7	537 11 58-01	INSULATING		1	1
8	735 58 41-00	WASHER		7	1
9	537 42 42-01	ALUMINIUM FOIL		1	1
10	537 41 54-01	CHASSIS		1	
11	503 21 59-12	SCREW IHSCT		4	10
12	537 21 77-01	BASE		4	10
13	503 89 47-01	SNAP LOCKING		4	10
14	504 10 76-01	SLEEVE		1	10
15	734 11 77-71	WASHER		1	10
16	735 31 15-20	E-CLIP		1	10
17	537 11 73-01	COVER	356BTx	1	
18	537 21 57-01	CHOKE CONTROL		1	
19	503 14 54-02	GROMMET		1	
20	735 31 13-20	E-CLIP	356BTx	1	
21	503 21 59-12	SCREW IHSCT		2	
22	537 19 33-01	GRID		1	
24	537 40 29-01	LABEL	356BTx	1	
25	537 40 29-02	LABEL	356BFx	1	



Ref	Part No	Description	Remark	QTY	KIT
1	537 19 25-01	HUB		1	
2	501 67 35-01	SPRING		2	
3	503 23 00-42	WASHER		2	
4	501 67 32-01	PAWL		2	
5	501 81 99-01	SCREW		2	
6	503 22 04-01	NUT		1	
7	537 18 89-01	IMPELLER		1	
8	537 21 72-01	ATTACHMENT PLATE		1	
9	503 20 49-01	SCREW IH PANM		4	
10	544 28 37-01	FAN HOUSING		1	
11	503 21 75-25	SCREW IH SCFT		5	
12	537 25 27-01	ANTIVIBRATION ELEMENT		2	
13	503 20 07-12	SCREW IH SCFM		4	
14	537 29 79-01	AIR CONDUCTOR		1	
15	503 21 66-10	SCREW IH SCT		3	
16	537 30 01-01	ANTIVIBRATION ELEMENT		2	
17	734 11 47-41	WASHER		2	
18	537 24 63-01	SCREW		2	
19	537 18 84-01	WEAR RING		2	
20	503 21 66-10	SCREW IH SCT		2	
21	537 28 18-01	AIR NOZZLE		1	
22	503 89 47-01	SNAP LOCKING		2	
23	537 21 78-01	GROMMET		1	
24	537 31 60-01	SCREW IH SCFM		2	
25	503 79 14-02	GROMMET		1	
26	503 22 10-15	HEXAGON NUT		2	
27	503 20 02-16	SCREW IH SCFM		7	
28	537 05 71-01	FAN HOUSING		1	
29	503 21 66-10	SCREW IH SCT		4	
30	537 27 07-01	AIR CONDUCTOR		1	
31	537 05 73-01	GUIDE PLATE		1	
32	544 43 80-01	INSULATION		1	
33	544 19 69-01	TAPE		1	32
34	544 43 80-01	INSULATION		1	32






## FUEL TANK

356 BT


Ref	Part No	Description	Remark	QTY	KIT
1	537 06 21-01	HUB CAP		1	
2	537 06 19-01	AIR FILTER		1	
3	537 06 20-01	GRID		1	
4	537 00 60-01	STARTER		1	
5	537 42 47-01	SPACER		1	4
6	537 42 53-01	SCREW		1	4
7	503 23 00-74	WASHER		1	4
8	501 89 67-03	STARTER PULLEY		1	4
9	503 43 29-04	STARTER CORD		1	4
10	503 13 50-01	RECOIL SPRING		1	4
11	504 04 93-02	STARTER HOUSING		1	4
12	735 31 11-00	CIRCLIP		1	11
13	504 10 49-01	SLEEVE		1	11
14	537 05 74-01	STARTER HOUSING		1	11
15	503 54 39-01	STARTER HANDLE		1	
16	503 20 78-10	SCREW IHSCFM		4	
17	537 38 82-01	COVER		1	
18	503 73 58-01	BUSHING		2	
19	503 93 66-01	PURGE		1	
20	537 04 24-08	FUEL HOSE		2	
21	537 04 24-11	FUEL HOSE		1	
22	503 44 32-01	FUEL FILTER		1	
23	504 03 18-01	TANK CAP ASSY		1	
24	537 11 61-01	FUEL TANK	ROW	1	
25	544 33 14-01	FUEL TANK	USA	1	




## CARBURETOR DETAILS

356 BT

Ref	Part No	Description	Remark	QTY	KIT
1	579 46 27-01	CARBURETTOR		1	
2	537 39 02-01	SHAFT ASSY		1	1
3	537 37 03-01	VALVE		1	1
4	503 48 18-01	SCREW		1	1
5	503 48 05-01	SCREW		2	1
6	503 97 43-01	COVER		1	1
7	504 11 35-01	DIAPHRAGM		1	1, 33
8	503 48 03-01	GASKET		1	1, 33
9	503 48 01-01	SCREW		1	1
10	503 48 00-01	PIN RETAINING SCREW		1	1
11	503 66 59-01	LEVER		1	1
12	537 02 03-01	SPRING		1	1
13	503 47 97-01	VALVE		1	1
14	503 53 56-01	PLUG WELCH		1	1
15	537 38 52-01	CLIP		1	1
16	537 01 26-01	SPRING		1	1
17	537 01 25-01	BALL		1	1
18	503 53 57-01	STRAINER		1	1
19	537 38 75-01	SCREW	H	1	1
20	537 41 69-01	SCREW	L	1	1
21	537 41 70-01	LIMITER CAP		2	1
22	537 01 97-01	SPRING		1	1
23	503 47 92-01	SCREW		1	1
24	537 39 01-01	VALVE		1	1
25	537 39 00-01	SHAFT ASSY		1	1
26	503 75 53-01	SCREW		1	1
27	537 02 00-01	DIAPHRAGM PUMP		1	1, 33
28	537 02 01-01	GASKET		1	1, 33
29	503 48 11-01	PIECE		1	1
30	537 02 07-01	SCREW		1	1
31	537 02 02-01	COVER		1	1
32	503 47 96-01	SCREW		1	1
33	537 24 36-01	GASKET KIT		1	



Ref	Part No	Description	Remark	QTY	KIT
1	504 56 86-01	HARNESS		1	
2	537 30 54-01	BUCKLE		1	1
4	503 21 52-02	SCREW		4	
5	537 30 53-01	BUCKLE		1	1
6	503 21 52-02	SCREW		4	



## ACCESSORIES

356 BT

Ref	Part No	Description	Remark	QTY	KIT
1	537 24 16-01	HANDLEBAR ASSY		1	
2	725 23 47-51	SCREW EHHM		1	1
3	502 20 40-01	KNOB		1	1
4	537 26 03-01	BRACKET		1	1
5	725 53 25-55	SCREW IHSCM		1	1
6	537 29 29-01	BRACKET		1	1
7	731 23 14-01	HEXAGON NUT		2	1
8	537 17 28-01	HANDLE		1	1
9	731 23 14-01	HEXAGON NUT		1	1
10	503 20 02-45	SCREW IHSCFM		1	1
11	537 17 29-01	COVER		1	1
12	537 24 13-01	HANDLEBAR		1	1
13	537 28 21-01	PIPE		1	
14	501 69 17-01	COMBINATION WRENCH		1	
15	503 55 86-01	SPANNER		1	